

Peugeot 206 2.0 Hdi 1999-2007

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

