

## Rover 75 2.0CDT 115HP 2004

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

